








**1. FOLD THE  
LAUNCHER LIKE  
THIS.**



**2. STAPLE A  
RUBBER BAND IN  
THE FRONT CENTER.**



**3. GLUE OR TAPE A PAPER CLIP,  
PULL BACK, AND LET IT FLY!!!**